



PWR_ADJ is only available for V721 and V770,
otherwise it is necessary to use an external 5V power
supply.



2 PWR_ADJ (5V)



UNIT VETRONICS